Creo Parametric 3.0 Lesson 21

Lesson 21 Pulley Assembly (Video Lesson)




Figure 21.1 Pulley Assembly

OBJECTIVES

- Use **Assembly** commands
- Establish and edit **Units**
- Apply Analysis to determine Global Interference and Global Clearance
- Measure features to analyze components fit
- Use **Edit Definition** features to resolve design problems
- Use **Top-Down Design** to create the **Pulley** and **Belt** components

RESOURCES

- Video Lecture can be downloaded directly.
- www.cengage.com > Search > Creo Parametric 3.0 > Free Materials
- Parts download at <u>www.cad-resources.com</u> > click on the appropriate book cover >



choose commercial or academic Pulley Assembly

Creo Parametric 3.0 Lesson 21

Steps

Follow the Steps to complete the lesson:

- **Download** the Lesson Lecture onto your hard drive
- Play directly from your computer using Windows Media Player (.wmv file)
- Use **Top-Down Design** to create the **Pulley** and **Belt** components
- Edit as necessary
- Follow the procedures in the Lesson Lecture
- Save the completed assembly (and its required components) as a single Zipped file
- **Upload** the **zipped** file to your Course Management System as an assignment if available.




Figure 21.2 Exploded Pulley Assembly